



— *Est. 1986* —



Spectra 400/405 Shower Screen & Walk-In

INSTALLATION INSTRUCTIONS

Issue 4 - September 2018

**We recommend the shower tray is fitted correctly and sealed, prior to tiling.
Tile down onto the tray and re-seal before installing shower enclosure.**

Spectra 400/405 Shower Screen & Walk-In

INSTALLATION INSTRUCTIONS

Ensure that shower enclosure area is tiled prior to installing the shower enclosure

Equipment Required For Installation

Power drill, 6mm masonry drill bit, tape measure, ruler, pencil, masking tape, sanitary grade silicone sealant, rubber mallet, posidrive screwdriver / bits, spirit level and the fitting kit supplied which includes wall plugs, screws, plastic tube and allen keys.

The components for the Spectra Shower Screen are packed in one box for Spectra 400 and two boxes for Spectra 405 comprising:-

- a) Straight Glass Screen b) Wall Fixing Brackets and Brace c) Fitting Kit d) Installation Instructions and e) Squeegee

Please open boxes with care and notify your supplier immediately if anything is damaged. Please do not discard packaging. Repack carefully if necessary.

- For wet room applications ensure the area is professionally sealed and flat where the screen meets the floor or walls. If fitting onto a shower tray follow manufacturer's installation instructions. Ensure the tray is level using a spirit level on at least two diagonals. Check the tray has been sealed correctly and sealant is cured before attempting to install the shower enclosure. We recommend sealing the tray prior to tiling, tiling down onto tray and re-sealing. The floor area around the tray should also be sealed and waterproof.
- The adjustable wall mounting profile has concealed fixings. Remove cover strip (B) slide out from main panel (A) and remove screws.
- Separate wall mounting rail from shower screen/ main panel.
- Locate the wall mounting rails in the correct position, 10mm in from edge of tray. Plumb true with spirit level. Place 3 horizontal strips of masking tape onto the tiles in line with the 3 pre-drilled slots in the mounting rails. Check for level and mark through holes with a pencil. Also mark tape at side of profile. Drill and plug the wall. Remove masking tape. Re-locate wall mounting rail, re-checking for plumb. Use the plastic tube from the fitting kit to hold the stainless steel screw provided, insert a posidrive screwdriver into the tube to locate the head of the screw. Locate the screw into the wall plug through the mounting rail (b). Tighten screws, re-checking with spirit level before tightening fully.
- Slide main panel (D) onto the wall mounting rail. Re-position screws into main wall profile, do not fully tighten until enclosure is assembled.
- 6a. Please Note:** If fitting the **Spectra 405** (Walk-in), go to step 7. Position chrome block 12.5mm in from the top edge of the screen. Position brace/steady bar wall socket centred at 1962mm up from tray and in line with the centre hole of the chrome block. Use masking tape to mark centres, check plumb and drill for wall plug, remove tape, insert wall plug and screw socket into position. Cut steady bar tubing to desired length. **6b.** Fit the tube into the chrome block and secure into position by tightening the grub screws. Fit the chrome finish cover caps into the block.
- Please Note:** If fitting the **Spectra 405** (Walk-in), position the second adjacent shower screen repeating the above instructions 2-5. **Position the first chrome block 12.5mm in from top edge of main screen.** Secure the second chrome block close to the top front edge of the glass. Adjust the length of the brace tube **between** to suit. **Fit tube in position in between the chrome block and T piece and tighten the grub screws.** Fit chrome cover caps into unused holes.
- Apply a continuous small bead of silicone caulking to the outside edges of the enclosure. Also seal the inside vertical wall profile edge and the bottom edge of the glass. Ensure a good seal is made and there are no pin holes in the sealant. **Do NOT seal the inside horizontal edges of the wall mounting rails to ensure that any water drains back into the tray/wet area.**

DO NOT USE THE SHOWER ENCLOSURE FOR 24 HOURS TO ENSURE SILICONE IS FULLY CURED AND WATERPROOF.

