









VOLA 1600

Fitting instruction
 Montageanleitung
 Monteringsvejledning
 Monteringsvægledning
 Montage hanleiding
 Manuel de montage

Data	Bar:	1	2	3	4	5
1611/1621	(l/min) (Gal/min)	13.4 3.5	18.9 5.0	23.2 6.1	26.8 7.1	30.0 7.9
1641	(l/min) (Gal/min)	11.4 3.0	16.2 4.3	19.8 5.3	22.9 6.1	25.6 6.8
1641 - T2	(l/min) (Gal/min)	6.6 1.74	9.4 2.5	11.5 3.0	13.3 3.5	14.8 3.9
1671 - T2	(l/min)	9.9	14.0	17.2	19.9	22.2
1671-HT2	(Gal/min)	2.6	3.7	4.5	5.3	5.9
	Max. 65°C. 150°F					








VOLA T2




VOLA T2




T4




T5




T6




T7




T11



T16



VOLA T3, T4, T5, T6, T7, T8, T9, T11, T14, T16, T27



www.vola.com


vola




5 1703182 372310

mmt_T3-T27_V2_40999247


T14




T8




T9




T3




T27




T4, T5, T6, T7, T11, T16, T27




T8, T9, T14



T3





VR090D/C: VR623, VR624C, 4xVR631, VR1902



vola
 Lunavej 2
 DK-8700 Horsens
 Tlf : + 45 7023 5500
 Fax: + 45 7023 5511
 sales@vola.com
 www.vola.com


VOLA 1641T8

Date
 Jan. 96



Rev.
 2

Sheet
 SB 50A

T2V:



T2:



VOLA A/S
Lunavej 2
DK-8700 Horsens
Tlf : + 45 7023 5500
Fax: + 45 7023 5511
sales@vola.com
www.vola.com

VOLA T2V & T2

Dato



Sep. 07

Rev.

1

Blad

SB 40



VOLA A/S
Lunavej 2
DK-8700 Horsens
Tlf : + 45 7023 5500
Fax: + 45 7023 5511
sales@vola.com
www.vola.com

VOLA T8

Dato

Jan. 96

Rev.

1

Blad

SB 40.6